Hardware User Manual



AcousticDesign™ Series


AD-C245C Zero Bezel Accessory AD-C305C Zero Bezel Accessory

The optional Zero Bezel Accessory for select AcousticDesign Series loudspeakers includes an adapter ring and a replacement magnetic grille that, once installed, covers the entire loudspeaker flange. Refer to the table to match the correct accessory model number to your loudspeaker:

Accessory Model	Part Number	Loudspeaker Compatibility
AD-C245C	FG-901617-02	AD-C6T-HP
		AD-C4T-LP
		AD-C6T
AD-C305C	FG-901618-02	AD-C6T-HC
		AD-C.SUB
		AD-C6T-LP

Mount the Loudspeaker: Zero Bezel Accessory

- 1. Place the adapter ring behind the loudspeaker flange and below the ceiling panel. See Figure 1.
- 2. Secure the loudspeaker's dog-ears. (Refer to your loudspeaker model's user manual for guidance.)
- 3. Insert the Zero Bezel magnetic grille's safety tether pin into the supplied hole on the loudspeaker baffle. See Figure 2.
- 4. Install the Zero Bezel grille, making sure that it's securely held in place. The old grille can be discarded, if desired.



TD-001703-01-A





Knowledge Base

Find answers to common questions, troubleshooting information, tips, and application notes. Link to support policies and resources, including Q-SYS Help, software and firmware, product documents, and training videos. Create support cases. support.gsys.com

Customer Support

Refer to the Contact Us page on the Q-SYS website for Technical Support and Customer Care, including their phone numbers and hours of operation.

qsys.com/contact-us/

Warranty

For a copy of the QSC Limited Warranty, go to: qsys.com/support/warranty-statement/